
Driver for 5800 Refrigerated Sampler USB Cable

Instruction Sheet #60-5802-102
Released: July 11, 2012

Installation Instructions

Overview

Before using the 5800 Sampler USB programming cable (part #69-5804-177), the device driver must first be installed on your computer.

These instructions provide the steps to access and install the driver.

Procedure

The USB driver can be accessed from www.isco.com.

1. Under **Service & Support**, click on Software/Firmware Updates.
2. Under Software/Firmware Updates (middle of the page), click on **Open Channel Flow Measurement**.
3. Under Open Channel Flow Measurement, click on **Driver - USB Interrogate Cable**.
4. Select the ZIP file Drivers for Isco USB Interrogation Cables.
5. From the WinZip window, select **Save** to create a set of these files in a temporary location such as C:\temp.
6. When the download is complete, right-click on the .zip folder and select **Open**.
7. Open the file **Virtual COM Port Driver Installation Instructions.pdf** and follow the driver installation instructions for your operating system.

Last modified July 13, 2012

Teledyne Isco

P.O. Box 82531, Lincoln, Nebraska, 68501 USA
Toll-free: (800) 228-4373 • Phone: (402) 464-0231 • Fax: (402) 465-3091
E-mail: iscoinfo@teledyne.com



Teledyne Isco is continually improving its products and reserves the right to change product specifications, replacement parts, schematics, and instructions without notice.